



## Water Sensor



Universal Indicator



OEM  
Interface  
Module



Mounting Brackets

**\*HARDWARE INCLUDED**



Sensor

Sensor

The water sensor kit is designed to operate with the fuel purifier. It alerts the user when the unit needs to be purged. When the water level in the purifier reaches the sensor level, an audible buzzer sounds, then a red indicator light turns on. The buzzer lasts only 10 seconds, but the light will remain lit until the unit is purged.